

Please read this instruction manual carefully prior to installation. Keep this manual readily accessible for future reference.




### ATTENTION


1. Upon installation, please ensure that your surrounding environment is clean, as it may affect its precision.
2. We shall not be held liable and shall not accept any liability, obligation, or responsibility whatsoever for any damage to the item during the course of assembly and/or disassembly.
3. Please seek professional assistance or advice if you are unclear about the instructions or have any doubts regarding the procedures.

## 1 PARTS INCLUDED (Y15ZR/LC135)


**1** RADIATOR Y15ZR




**2** GROMMET




**3** BRACKET



**4** DAMPER




**5** BOLT & NUT




## 1-1 PARTS INCLUDED (RS150R/RS-X)


**1** RADIATOR RS150




**2** GROMMET




**3** BRACKET



**4** DAMPER




**5** SCREW




## 1-2 PARTS INCLUDED (Y16ZR)


**1** RADIATOR Y16ZR



**2** GROMMET




**3** DAMPER




## 1-3 PARTS INCLUDED (NMAXv2/NVXv2)


**1** RADIATOR NMAXv2




**2** GROMMET



**3** DAMPER



**4** SPACER



## 2 DISCLAIMER

Please ensure the contents in this package matches the above diagram/part ( 1 & 1-3 ). If there are missing parts, kindly refer to the place you bought from.

Seek professional help if you have difficulties installing our products.